


Dimensions of Zipper

When measuring a zipper, close it and measure from the bottom end of bottom stop to the top end of the slider. Care should be taken because some tolerance is included in the indication of zipper dimensions.


Note: For products with special conditions affecting the dimensions, the above tolerance may not apply

Product Dimensions	Maximum tolerance allowed in dimension indication
Less than 30cm	±5mm
30 cm or more (less than 60cm)	±10mm
60cm or more (less than 100cm)	±15mm
100cm or more	3% of dimension indicated


Standard for measuring zipper dimensions (Based on JIS - 3015)



Close End
Length : From the top end of the slider to the bottom stop.



Head to head
Length : From the top of one bottom stop to the bottom of the other bottom stop (C-Type).



Back to Back
Length : From the top of one slider to the top of the other slider (X Type).



Open End
Length : From the top end of the slider to the bottom of the box.



Two way separator
Length : From the top end of the slider to the bottom end of the supplementary tape.



Reversible Slider
Length : Measurement should be made from the shoulder inlet portion of the slider.